

- Check the "Main Schematic" folder to learn more about all possible features and options.
- Make sure to program AVR64DB64 Flash, EEPROM and Fuses with the files and instructions provided in the "Bootloader" folder!

- The Estlcam hardware designs are free:
 - You are allowed to manufacture and sell Estlcam compatible hardware.
 - Actually I really appreciate it if you do so:
 - I'm a hardware and software development guy and get my income from the Estlcam software license sales.
 - I'm not much interested in manufacturing and hardware sales, especially not internationally.

- 1: Your product = your responsibility.
 - Do everything at your own risk and don't hold me liable.
 - Ensuring the products compliance to your intended markets laws and regulations is up to you.
- 2: Put your company name and address on the finished product:
 - Customers must be able to tell who manufactured the product.
 - You are allowed to use the Estlicam logo – this is OK.

christian@eslicam.de www.eslicam.de Esticam / Christian Knüll		
Sheet: / File: LPT_XL.kicad_sch		
Title: Esticam Terminal Adapter "XL"		
Size: A1	Date: 2024-06-22	Rev: A
KiCad E.D.A. 8.0.1		Id: 1/1

